

DEPARTMENT OF PUBLIC HEALTH AND ENVIRONMENT **GOVERNMENT CENTER**

14949 62nd STREET NORTH P.O. BOX 6 STILLWATER, MN 55082-0006 Office: 651-430-6655 TTY: 651-430-6246 FAX: 651-430-6730

Subsurface Sewage Treatment System Maintenance Permit

This section must be completed in its entirety to constitute a valid maintenance permit. This permit must be completed					
prior to performing maintenance activities and remain on-site for the duration of the maintenance activity.					
Date of Maintenance: Reason for Maintenance:					
Property Address: 5350-850-61					
Municipality: 5Hllwater ZIP: Property Identification Number:					
Maintenance Permit No:					
Maintenance Performed		Tank Measurement (must be completed if tanks NOT pumped)			
Tank(s) Pumped		Liquid Level of Tank in			
☐ Sludge and scum measured		Sludge Level in Tank in Scum Level in Tank in			
Do tanks need to be pumped?		Sludge + Scum / Liquid Level X 100			
\square Yes \square No (if no provide measurements)		= % Sludge & Scum Tanks must be pumped if 25% or greater			
 Access used to remove septage: Maintenance Hole Other (enter authorization code) Were all covers securely replaced? Yes No Is there evidence of tank leakage from a septic, holding, pretreatment or pump tank below the operating depth or evidence of damaged, cracked, or structurally unsound maintenance hole covers? 					
Tanl	ζ	Leaking Out	Leaking In	Cover Damage	
Septic/Holding T	ank #1	☐ Yes KNo	☐ Yes No	☐ Yes No	
Septic/Holding T	ank #2	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	
Pretreatment Ta	ink	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	
Pump Tank		☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No	
4. How many gallons of septage were removed?					
Tank #1 /520 gal Tank #2	gal Pretreatment	tankga	al Pump Tank	gal	
5. Other information: List any troubleshooting, minor repairs conducted, tank safety concerns, or other concerns.					
6. Location of septage disposal:					