

DEPARTMENT OF PUBLIC HEALTH AND ENVIRONMENT

GOVERNMENT CENTER

14949 62nd STREET NORTH P.O. BOX 6 STILLWATER, MN 55082-0006 Office: 651-430-6655 TTY: 651-430-6246 FAX: 651-430-6730

Subsurface Sewage Treatment System Maintenance Permit

This section must be completed in its entirety to constitute a valid maintenance permit. This permit must be completed						
prior to performing maintenance activities and remain on-site for the duration of the maintenance activity.						
Date of Maintenance: 10/3/16 Reason for Maintenance: Routine						
Property Address:	495 Dorma	naven 1	Property Owner's N	Jame: Norm L	Jupre	
Municipality: Root	// //			/	/	
Municipality: Say town / May ZIP: 5508 Property Identification Number: Maintenance Permit No: p 2386 / 4305 Maintainer Name and License No. Meyer Sewer Service / L915						
Maintenance Perimit No	h 2386/4305 M	Maintainer Name ar	nd License No. Mey	er Sewer Service/ L91	15	
Maintenance Performed		Tank Meas	Tank Measurement (must be completed if tanks NOT pumped)			
Tank(s) Pumped		Liquid Level of Tank in				
☐ Sludge and scum measured		Sludge Level in Tank in Scum Level in Tank in				
Do tanks need to be pumped?		Sludge + Scum / Liquid Level X 100				
\square Yes \square No (if no provide measurements)		= % Sludge & Sci	= % Sludge & Scum Tanks must be pumped if 25% or greater			
1. Access used to remove septage: Maintenance Hole □ Other (enter authorization code)						
3. Is there evidence of tank leakage from a septic, holding, pretreatment or pump tank below the operating depth or evidence of damaged, cracked, or structurally unsound maintenance hole covers?						
-	Tank	Leaking Out	Leaking In	Cover Damage		
Ī	Septic/Holding Tank #1	☐ Yes 🄀 No	☐ Yes 🎾 No	☐ Yes No		
	Septic/Holding Tank #2	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No		
	Pretreatment Tank	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No		
	Pump Tank	☐ Yes ☐ No	☐ Yes ☐ No	☐ Yes ☐ No		
4. How many gallons of septage were removed?						
Tank #1 1505	gal Tank #2	gal Pretreatmen	t tankg	gal Pump Tank	gal	
5. Other information: List any troubleshooting, minor repairs conducted, tank safety concerns, or other concerns.						
6. Location of septage disposal: LST 57, TAUL						