

## DEPARTMENT OF PUBLIC HEALTH AND ENVIRONMENT GOVERNMENT CENTER

14949 62nd STREET NORTH P.O. BOX 6 STILLWATER, MN 55082-0006 Office: 651-430-6655 TTY: 651-430-6246 FAX: 651-430-6730

## Subsurface Sewage Treatment System Maintenance Permit

| This section must be completed in its entirety                         | to constitute a va                                       | lid maintenance p                             | ermit. This permit   | must be completed |  |
|--|--|---|----------------------|-------------------|--|
| prior to performing maintenance activit                                | ies and remain on  | -site for the durat                           | ion of the maintena  | ance activity.    |  |
| Date of Maintenance: 6-28-/6 Reason                                    | for Maintenance:   | Cleaning                                      |                      |                   |  |
| Property Address: 6320 17714 5+  | N  | Property Owner's N                            | ame: Rudy H          | lartheben         |  |
| Municipality: Hugo ZIP: 550  |  |   |                      |                   |  |
|  |  |   |                      |                   |  |
| Maintenance Permit No: 12613 m 2974                                    | Maintainer Name ar                                       | nd License No. Smi                            | lie's Sewer Service/ | L2428             |  |
| Maintenance Performed  | Tank Meas  | surement (must be                             | completed if tanks   | NOT pumped)       |  |
| ☐ Tank(s) Pumped   | Liquid Level of  | Liquid Level of Tank in                       |                      |                   |  |
|  |  | Sludge Level in Tank in Scum Level in Tank in |                      |                   |  |
| Sludge and scum measured  Do tanks need to be pumped?                  | Sludge + Scum / Liquid Level X 100                       |   |                      |                   |  |
| ☐ Yes ☐ No (if no provide measurements)                                | = % Sludge & Scum Tanks must be pumped if 25% or greater |   |                      |                   |  |
| Access used to remove septage:   | □ No<br>otic, holding, pret                              | reatment or pump                              | tank below the ope   | erating depth or  |  |
| Tank   | Leaking Out  | Leaking In                                    | Cover Damage         |                   |  |
| Septic/Holding Tank #1   | ☐ Yes ☐ No   | ☐ Yes ☐ No                                    | ☐ Yes ☐ No           |                   |  |
| Septic/Holding Tank #2   | ☐ Yes ☐ No   | ☐ Yes ☐ No                                    | ☐ Yes ☐ No           |                   |  |
| Pretreatment Tank  | ☐ Yes ☐ No   | ☐ Yes ☐ No                                    | ☐ Yes ☐ No           |                   |  |
| Pump Tank  | ☐ Yes ☐ No   | ☐ Yes ☐ No                                    | ☐ Yes ☐ No           |                   |  |
| 4. How many gallons of septage were removed  Tank #1 / 500 gal Tank #2 |  | t tank g                                      | al Pump Tank         | 300 gal           |  |
| 5. Other information: List any troubleshooting                         |  |   |                      |                   |  |
| 6. Location of septage disposal:                                       |  |   |                      |                   |  |